# THE MATH OF NFPA 70E: Standard for Electrical Safety in the Workplace®



HANGE

Every three years, the National Fire Protection Association (NFPA) updates its 70E standard to help facilities avoid the effects of electrocution and arc flash incidents. The 2015 additions, subtractions, and other changes build on the safety, training and maintenance requirements of the 2012 standard to facilitate even greater mitigation of electrical hazards.

2012		2015
TERMINOLOGY		
"Hazard" and "risk" used without definition clarity	≠	Hazard: Potential for harm from exposed energized electrical conductors and/or the condition of equipment Risk: Chance or probability that the hazard could result in physical harm
Uses the terms "arc flash hazard analysis," "shock hazard analysis," and "electrical hazard analysis"	$\Delta$	Uses "arc flash risk assessment," "shock risk assessment," and "electrical risk assessment"
References hazard risk categories (HRC)	$\Delta$	References arc flash personal protective equipment (PPE) categories
Mentions limited, restricted and prohibited approach boundaries		Prohibited approach boundary

# **QUALIFICATION**

A qualified person shall be trained and **knowledgeable** in the construction and operation of equipment or specific work methods



## **WORK PRACTICES**

Limits the use of tables when determining arc flash



Additional limitations regarding the "table method" to encourage use of engineering analyses

#### LABELING

Must include nominal system voltage, arc flash boundary and one of the following: minimum arc rating of clothing; required level of PPE or highest HRC

Arc flash labels should be applied to AC and DC equipment

Should be updated periodically and when any major modification or renovation takes place, not to exceed 5 years

Option of including available incident energy and the corresponding working distance as one of the additional pieces of information



Label requirements for switchboards, switchgear, panel boards, industrial control panels, meter socket enclosures, and motor control panels



The stipulation to update labels when the hazard risk assessment shows the labels are inaccurate

### **RISK ASSESSMENT & WORK PERMITS**

Required when work is planned within the limited approach boundary of exposed energized conductors or circuit parts; and when an increased risk exists



The need for a permit plan for tasks that are routine in nature and performed by a qualified person such as testing, troubleshooting, visually inspecting, etc.

Table 130.7 (C)(15)(b) shows HRC values for DC
locations although calculating the HRC values is a
preferable approach



Required risk assessment prior to work on a battery system based on use of newly revised DC task-based tables

#### **GENERAL MAINTENANCE**

Electrical equipment, including overcurrent protective devices, must be maintained in accordance with manufacturers' instructions or industry consensus standards



The stipulation that the equipment owner is responsible for the maintenance and its documentation

#### UNDERSTANDING THE MATH OF NFPA 70E CAN BE A CHALLENGE, BUT VERTIV™ CAN BE YOUR TUTOR! For help protecting your critical assets and achieving regulatory compliance, call a local sales representative today at 1-800-LIEBERT.

© 2016 Vertiv Co. All rights reserved. Vertiv, the Vertiv logo and Vertiv are trademarks or registered trademarks of Vertiv Co. All other names and logos referred to are trade names, trademarks or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness herein, Vertiv Co. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications are subject to change without notice